

## GENERAL INFORMATION

## INSTALLATION DRAWINGS

### Submersible Accessories

#### A. Panels and Accessories:

- Control Panels - Submersible Non-Clogs & Effluent
- Stealth Grinder Control Panels
- Starters & Contactors
- Alarm/Disconnect Panel
- Alarms
- Capacitor/Relay Packs

#### B. Break Away Fittings

- 1¼" Thru 3" BAF, Standard & Non-Sparking, Vertical Discharge Pumps
- Pump Stands
- 1¼" Hydromatic Adapter
- 2" Hydromatic Adapter
- 1¼" & 2" C-Channel, Moveables & Intermediates
- 3" BAF's Non-Sparking, Horizontal Discharge Pumps
- 4" BAF's - 4x4, 4x6
- 4" Moveable BAF-4, BAF-E4
- 4" Hydromatic Adapter
- 4" & 6" Flygt Adapter
- 6" BAF's
- 8" BAF's
- Intermediate Rail Supports

#### C. Basins and Accessories

- Basins, Covers & Accessories
- Access Doors
- Valves
- Level Controls
- Junction Boxes
- Pump Hoists