

Repair Kit Cross Reference

Pump Model	Pump PN	Pump Manual PN	Seal & Gasket Kit PN	Service / Overhaul Kit PN	Bearing Kit PN	"O" Ring Kit	Cutter Kit PN	BAF PN	BAF-xxxx-CV PN
3CCE	027458	022567	021814						
3CCE-1	027460	022567	021814						
4CCE	027464	022567	021814						
4CCE-1	027466	022567	021814						
5CCE	027470	022567	021814						
5CCE-1	027472	022567	021814						
10CCE	028506	022567	072920						
10CCE-1	028504	022567	072920						
15CCE	028508	022567	072918						
20CCE	028510	022567	072918						
25CCE	028512	022567	072918						
5CU-1	019130	022568	120742						
7CU-1	018902	022568	120742						
SFU102	087785	026882		085244					
SFU31	087781	026882		085244					
SFU51	087782	026882		085244					
SFU71	087783	026882		085244					
SFU72	087784	026882		085244					
2020HCU	029676	030174	083560						
10ICU-1	033762	033825	085238	085239					
4030HCU	059459	052320	083562						
15ICU-1	052596	052350	085241	085240					
20ICU-1	052624	052350	085241	085240					
25ICU-1	052626	052350	085241	085240					
SED50	068829	070267	085204	085207					
SED52	068831	070267	085204	085207					
SED55	068834	070267	085204	085207					
SED56	068835	070267	085204	085207					
XSGV3002L	084537	082188					085225		
4SE1926L	084602 *	084830	130178	130174				128281	
4SE1946L	084605 *	084830	130178	130174				128281	
4SE1956L	089300 *	084830	130178	130174				128281	
4SE1996L	084604 *	084830	130178	130174				128281	
4SE2824L	084606 *	084830	130178	130174				128281	
4SE2826L	088825 *	084830	130178	130174				128281	

NOTE:

For a list of components in the kits refer to the pump manual.
 * Previous Model Listings (see page 36)



PUMPS & SYSTEMS

SECTION	RP-KIT
PAGE	1
DATE	7/12

Repair Kit Cross Reference

Pump Model	Pump PN	Pump Manual PN	Seal & Gasket Kit PN	Service / Overhaul Kit PN	Bearing Kit PN	"O" Ring Kit	Cutter Kit PN	BAF PN	BAF-xxxx-CV PN
4SE2844L	084609 *	084830	130178	130174				128281	
4SE2846L	088827 *	084830	130178	130174				128281	
4SE2854L	089301 *	084830	130178	130174				128281	
4SE2856L	088828 *	084830	130178	130174				128281	
4SE2894L	084608 *	084830	130178	130174				128281	
4SE2896L	088826 *	084830	130178	130174				128281	
4SE3724L	084610 *	084830	130178	130174				128281	
4SE3744L	084612 *	084830	130178	130174				128281	
4SE3754L	089302 *	084830	130178	130174				128281	
4SE3794L	084611 *	084830	130178	130174				128281	
4SE5024L	088821 *	084830	130178	130174				128281	
4SE5032L	088829 *	084830	130178	130174				128281	
4SE5042L	088830 *	084830	130178	130174				128281	
4SE5044L	088823 *	084830	130178	130174				128281	
4SE5052L	088831 *	084830	130178	130174				128281	
4SE5054L	088824 *	084830	130178	130174				128281	
4SE5094L	088822 *	084830	130178	130174				128281	
4SE11334HL	084644	084831	130179	130175				128281	
4SE11334L	084632	084831	130179	130175				128281	
4SE11344HL	084645	084831	130179	130175				128281	
4SE11344L	084633	084831	130179	130175				128281	
4SE11346L	084622	084831	130179	130175				128281	
4SE11354HL	089316	084831	130179	130175				128281	
4SE11354L	089308	084831	130179	130175				128281	
4SE11356L	089305	084831	130179	130175				128281	
4SE11364L	084631	084831	130179	130175				128281	
4SE11396L	084621	084831	130179	130175				128281	
4SE15034HL	084646	084831	130179	130175				128281	
4SE15034L	084634	084831	130179	130175				128281	
4SE15044HL	084647	084831	130179	130175				128281	
4SE15044L	084635	084831	130179	130175				128281	
4SE15054HL	089317	084831	130179	130175				128281	
4SE15054L	089309	084831	130179	130175				128281	
4SE4524L	084623	084831	130179	130175				128281	
4SE4534L	084625	084831	130179	130175				128281	
4SE4544L	084626	084831	130179	130175				128281	

NOTE:

For a list of components in the kits refer to the pump manual.

* Previous Model Listings (see page 36)

Repair Kit Cross Reference

Pump Model	Pump PN	Pump Manual PN	Seal & Gasket Kit PN	Service / Overhaul Kit PN	Bearing Kit PN	"O" Ring Kit	Cutter Kit PN	BAF PN	BAF-xxxx-CV PN
4SE4546L	084616	084831	130179	130175				128281	
4SE4554L	089306	084831	130179	130175				128281	
4SE4556L	089303	084831	130179	130175				128281	
4SE4564L	084624	084831	130179	130175				128281	
4SE4596L	084615	084831	130179	130175				128281	
4SE7524HL	084641	084831	130179	130175				128281	
4SE7524L	084627	084831	130179	130175				128281	
4SE7534HL	084642	084831	130179	130175				128281	
4SE7534L	084629	084831	130179	130175				128281	
4SE7544HL	084643	084831	130179	130175				128281	
4SE7544L	084630	084831	130179	130175				128281	
4SE7546L	084619	084831	130179	130175				128281	
4SE7554HL	089315	084831	130179	130175				128281	
4SE7554L	089307	084831	130179	130175				128281	
4SE7556L	089304	084831	130179	130175				128281	
4SE7564L	084628	084831	130179	130175				128281	
4SE7596L	084618	084831	130179	130175				128281	
4SEU15032L	088835	084831	130179	130175				128281	
4SEU15032L	088835	084831	130179	130175				128281	
4SEU15034L	088832	084831	130179	130175				128281	
4SEU15042L	088836	084831	130179	130175				128281	
4SEU15042L	088836	084831	130179	130175				128281	
4SEU15044L	088833	084831	130179	130175				128281	
4SEU15052L	088837	084831	130179	130175				128281	
4SEU15052L	088837	084831	130179	130175				128281	
4SEU15054L	088834	084831	130179	130175				128281	
6SE12046L	084653	084833	085205	085208					
6SE12056L	089183	084833	085205	085208					
6SE12096L	084652	084833	085205	085208					
6SE18034L	084663	084833	085205	085208					
6SE18044L	084664	084833	085205	085208					
6SE18046L	084656	084833	085205	085208					
6SE18054L	089187	084833	085205	085208					
6SE18056L	089184	084833	085205	085208					
6SE18096L	084655	084833	085205	085208					

NOTE:

For a list of components in the kits refer to the pump manual.
 * Previous Model Listings



Repair Kit Cross Reference

Pump Model	Pump PN	Pump Manual PN	Seal & Gasket Kit PN	Service / Overhaul Kit PN	Bearing Kit PN	"O" Ring Kit	Cutter Kit PN	BAF PN	BAF-xxxx-CV PN
6SE24034L	084665	084833	085205	085208					
6SE24044L	084666	084833	085205	085208					
6SE24046L	084659	084833	085205	085208					
6SE24054L	089188	084833	085205	085208					
6SE24056L	089185	084833	085205	085208					
6SE24096L	084658	084833	085205	085208					
6SE30034HL	084680	084833	085205	085208					
6SE30034L	084667	084833	085205	085208					
6SE30044HL	084681	084833	085205	085208					
6SE30044L	084668	084833	085205	085208					
6SE30046L	084662	084833	085205	085208					
6SE30054HL	089177	084833	085205	085208					
6SE30054L	089189	084833	085205	085208					
6SE30056L	089186	084833	085205	085208					
6SE30096L	084661	084833	085205	085208					
6SE36034HL	084682	084833	085205	085208					
6SE36034L	084669	084833	085205	085208					
6SE36044HL	084683	084833	085205	085208					
6SE36044L	084670	084833	085205	085208					
6SE36054HL	089178	084833	085205	085208					
6SE36054L	089190	084833	085205	085208					
6SE48044HL	084684	084833	085205	085208					
6SE48044L	084671	084833	085205	085208					
6SE48054HL	089179	084833	085205	085208					
6SE48054L	089191	084833	085205	085208					
6SE60044HL	084685	084833	085205	085208					
6SE60044L	084672	084833	085205	085208					
6SE60054HL	089180	084833	085205	085208					
6SE60054L	089192	084833	085205	085208					
6SE75044HL	084686	084833	085205	085208					
6SE75044L	084673	084833	085205	085208					
6SE75054HL	089181	084833	085205	085208					
6SE75054L	089193	084833	085205	085208					

NOTE:

For a list of components in the kits refer to the pump manual.

* Previous Model Listings

Repair Kit Cross Reference

Pump Model	Pump PN	Pump Manual PN	Seal & Gasket Kit PN	Service / Overhaul Kit PN	Bearing Kit PN	"O" Ring Kit	Cutter Kit PN	BAF PN	BAF-xxxx-CV PN
6SE9046L	084650	084833	085205	085208					
6SE9056L	089182	084833	085205	085208					
6SE9096L	084649	084833	085205	085208					
8SE24038HL	084687	084893	085228	085229					
8SE24048HL	084688	084893	085228	085229					
8SE24058HL	089171	084893	085228	085229					
8SE36036HL	084689	084893	085228	085229					
8SE36046HL	084699	084893	085228	085229					
8SE36056HL	089172	084893	085228	085229					
8SE48046HL	084691	084893	085228	085229					
8SE48056HL	089173	084893	085228	085229					
9-01000		085969		9-01354		9-01353			
9-01300		085969		9-01354		9-01353			
4SE2824SS	088714	088688	130182	130209				128281	
4SE2826SS	088726	088688	130182	130209				128281	
4SE2836SS	088727	088688	130182	130209				128281	
4SE2844SS	088716	088688	130182	130209				128281	
4SE2846SS	088728	088688	130182	130209				128281	
4SE2854SS	088717	088688	130182	130209				128281	
4SE2856SS	088729	088688	130182	130209				128281	
4SE2894SS	088715	088688	130182	130209				128281	
4SE3724SS	088718	088688	130182	130209				128281	
4SE3744SS	088720	088688	130182	130209				128281	
4SE3754SS	088721	088688	130182	130209				128281	
4SE3794SS	088719	088688	130182	130209				128281	
4SE5024SS	088722	088688	130182	130209				128281	
4SE5032SS	088733	088688	130182	130209				128281	
4SE5042SS	088734	088688	130182	130209				128281	
4SE5044SS	088724	088688	130182	130209				128281	
4SE5052SS	088735	088688	130182	130209				128281	
4SE5054SS	088725	088688	130182	130209				128281	
4SE5094SS	088723	088688	130182	130209				128281	

NOTE:

For a list of components in the kits refer to the pump manual.
 * Previous Model Listings



Repair Kit Cross Reference

Pump Model	Pump PN	Pump Manual PN	Seal & Gasket Kit PN	Service / Overhaul Kit PN	Bearing Kit PN	"O" Ring Kit	Cutter Kit PN	BAF PN	BAF-xxxx-CV PN
3SE1022DS	088803	088743	130178	130174				127304	
3SE1032DS	088804	088743	130178	130174				127304	
3SE1042DS	088805	088743	130178	130174				127304	
3SE1052DS	088806	088743	130178	130174				127304	
3SE1522DS	088807	088743	130178	130174				127304	
3SE1532DS	088808	088743	130178	130174				127304	
3SE1542DS	088809	088743	130178	130174				127304	
3SE1552DS	088810	088743	130178	130174				127304	
3SE2022DS	088811	088743	130178	130174				127304	
3SE2032DS	088812	088743	130178	130174				127304	
3SE2042DS	088813	088743	130178	130174				127304	
3SE2052DS	088814	088743	130178	130174				127304	
3SE3024DS	088817 *	088743	130178	130174				127304	
3SE3032DS	088815	088743	130178	130174				127304	
3SE3034DS	088818 *	088743	130178	130174				127304	
3SE3042DS	088816	088743	130178	130174				127304	
3SE3044DS	088819 *	088743	130178	130174				127304	
3SE3052DS	089296	088743	130178	130174				127304	
3SE3054DS	088820 *	088743	130178	130174				127304	
3SE3024L	088799 *	088774	130182	130209				127304	
3SE3032L	088730 *	088774	130182	130209				127304	
3SE3034L	088800 *	088774	130182	130209				127304	
3SE3042L	088731 *	088774	130182	130209				127304	
3SE3044L	088801 *	088774	130182	130209				127304	
3SE3052L	088732 *	088774	130182	130209				127304	
3SE3054L	088802 *	088774	130182	130209				127304	
3SE1022L	085535	088887	130181	130208				127304	
3SE1042L	085537	088887	130181	130208				127304	
3SE1052L	089291	088887	130181	130208				127304	
3SE1092L	085536	088887	130181	130208				127304	
3SE1522L	085538	088887	130181	130208				127304	
3SE1542L	085540	088887	130181	130208				127304	
3SE1552L	089292	088887	130181	130208				127304	
3SE1592L	085539	088887	130181	130208				127304	

NOTE:

For a list of components in the kits refer to the pump manual.

* Previous Model Listings (see pages 36 and 37)

Repair Kit Cross Reference

Pump Model	Pump PN	Pump Manual PN	Seal & Gasket Kit PN	Service / Overhaul Kit PN	Bearing Kit PN	"O" Ring Kit	Cutter Kit PN	BAF PN	BAF-xxxx-CV PN
3SE2022L	085541	088887	130181	130208				127304	
3SE2042L	085543	088887	130181	130208				127304	
3SE2052L	089293	088887	130181	130208				127304	
3SE2092L	085542	088887	130181	130208				127304	
3SE1524L	085527	088888	130181	130208				127304	
3SE1544L	085530	088888	130181	130208				127304	
3SE1554L	089289	088888	130181	130208				127304	
3SE1594L	085529	088888	130181	130208				127304	
3SE2024L	085531	088888	130181	130208				127304	
3SE2044L	085534	088888	130181	130208				127304	
3SE2054L	089290	088888	130181	130208				127304	
3SE2094L	085533	088888	130181	130208				127304	
3SE1524DS	084921	088889	130177	130173				127304	
3SE1544DS	084930	088889	130177	130173				127304	
3SE1554DS	089294	088889	130177	130173				127304	
3SE1594DS	084927	088889	130177	130173				127304	
3SE2024DS	084937	088889	130177	130173				127304	
3SE2044DS	084940	088889	130177	130173				127304	
3SE2054DS	089295	088889	130177	130173				127304	
3SE2094DS	084939	088889	130177	130173				127304	
PO2LA	2C00D-0006C-001	094862	089076	089087					
PO3LA-7B	3CO1D-0007-B-031	094862	089077	089088					
PO3LA-8D	3CO1D-0008D-031	094862	089077	089088					
PO3LB-7B	3CO3D-0007-B-031	094862	089077	089088					
PO3LC-8L	3CO6D-0008-L-031	094862	089078	089089					
PO4LA-8D	4CO2D-0008D-031	094862	089078	089089					
PO4LA-9D	4CO2D-0009D-031	094862	089078	089089					
PO4LB-8D	4CO4D-0008D-031	094862	089078	089089					

NOTE:

For a list of components in the kits refer to the pump manual.
 * Previous Model Listings



Repair Kit Cross Reference

Pump Model	Pump PN	Pump Manual PN	Seal & Gasket Kit PN	Service / Overhaul Kit PN	Bearing Kit PN	"O" Ring Kit	Cutter Kit PN	BAF PN	BAF-xxxx-CV PN
PO4LC-9D	4CO7D-0009D-031	094862	089079	089090					
PO4LC-9L	4CO7D-0009-L-031	094862	089079	089090					
PO4LC-10D	4CO7D-0010D-031	094862	089079	089090					
PO4LC-10L	4CO7D-0010-L-031	094862	089079	089090					
PO6LB-10N	6C05D-0010N-031	094862	089080	089091					
PO6LB-11J	6C05D-0011-J-031	094862	089080	089091					
PO6LB-12F	6C05D-0012-F-031	094862	089080	089091					
PO6LC-13B	6C08D-0013-B-031	094862	089080	089092					
PO6LC-14X	6C08D-0014-X-031	094862	089080	089092					
9-20000		096926		9-500580		9-500574			
9-25000		096926		9-500580		9-500574			
9-27000		096926		9-500580		9-500574			
9-35000		096926		9-500580		9-500574			
9-50000		096926		9-500580		9-500574			
9-55000		096926		9-550580		9-500574			
9-81000		096928		9-815580		9-815574			
9-81500		096928		9-815580		9-815574			
9-82500		096928		9-840582		9-840574			
9-85000		096928		9-850582		9-840574			
9-79200		096932		9-705580		9-705574			
9-79300		096932		9-705580		9-705574			
9-79400		096932		9-705580		9-705574			
9-79500		096932		9-705580		9-705574			
BP314	096727	098846	085202	085201				127302	127309
BP314	096727	098846	085202	085201				127302	127309
BP314A	096728	098846	085202	085201				127302	127309
BP314A	096728	098846	085202	085201				127302	127309
BP314ABR	096733	098846	085202	085201				127302	127309
BP314ABR	096733	098846	085202	085201				127302	127309

NOTE:

For a list of components in the kits refer to the pump manual.

* Previous Model Listings

Repair Kit Cross Reference

Pump Model	Pump PN	Pump Manual PN	Seal & Gasket Kit PN	Service / Overhaul Kit PN	Bearing Kit PN	"O" Ring Kit	Cutter Kit PN	BAF PN	BAF-xxxx-CV PN
BP314AU	096729	098846	085202	085201				127302	127309
BP314AU	096729	098846	085202	085201				127302	127309
BP314AUBR	096734	098846	085202	085201				127302	127309
BP314AUBR	096734	098846	085202	085201				127302	127309
BP314BR	096732	098846	085202	085201				127302	127309
BP314BR	096732	098846	085202	085201				127302	127309
BP314HT	096737	098846	085202	085201				127302	127309
BP314HTA	096738	098846	085202	085201				127302	127309
BP314HTABR	096743	098846	085202	085201				127302	127309
BP314HTAU	096739	098846	085202	085201				127302	127309
BP314HTAUBR	096744	098846	085202	085201				127302	127309
BP314HTBR	096742	098846	085202	085201				127302	127309
BP314VF	100834	098846	085202	085201				127302	127309
BP314VF	100834	098846	085202	085201				127302	127309
BP314VFBR	100835	098846	085202	085201				127302	127309
BP314VFBR	100835	098846	085202	085201				127302	127309
BP324	096730	098846	085202	085201				127302	127309
BP324	096730	098846	085202	085201				127302	127309
BP324AU	096731	098846	085202	085201				127302	127309
BP324AU	096731	098846	085202	085201				127302	127309
BP324AUBR	096736	098846	085202	085201				127302	127309
BP324AUBR	096736	098846	085202	085201				127302	127309
BP324BR	096735	098846	085202	085201				127302	127309
BP324BR	096735	098846	085202	085201				127302	127309
BP324HT	096740	098846	085202	085201				127302	127309
BP324HTAU	096741	098846	085202	085201				127302	127309
BP324HTAUBR	096746	098846	085202	085201				127302	127309
BP324HTBR	096745	098846	085202	085201				127302	127309
SE411	096747	098846	085202	085201				127302	127309
SE411A	096748	098846	085202	085201				127302	127309
SE411ASP	103135	098846	085202	085201				127302	127309
SE411AU	096749	098846	085202	085201				127302	127309
SE411HT	096764	098846	085202	085201				127302	127309
SE411HTA	096765	098846	085202	085201				127302	127309
SE411HTAU	096766	098846	085202	085201				127302	127309

NOTE:

For a list of components in the kits refer to the pump manual.
 * Previous Model Listings



Repair Kit Cross Reference

Pump Model	Pump PN	Pump Manual PN	Seal & Gasket Kit PN	Service / Overhaul Kit PN	Bearing Kit PN	"O" Ring Kit	Cutter Kit PN	BAF PN	BAF-xxxx-CV PN
SE411-SP	084283B	098846	085202	085201				127302	127309
SE411VF	100836	098846	085202	085201				127302	127309
SE411VF	100836	098846	085202	085201				127302	127309
SE421	096750	098846	085202	085201				127302	127309
SE421AU	096751	098846	085202	085201				127302	127309
SE421HT	096767	098846	085202	085201				127302	127309
SE421HTAU	096768	098846	085202	085201				127302	127309
SE511	096752	098846	085202	085201				127302	127309
SE511A	096753	098846	085202	085201				127302	127309
SE511AU	096754	098846	085202	085201				127302	127309
SE511VF	100837	098846	085202	085201				127302	127309
SE521	096755	098846	085202	085201				127302	127309
SE521AU	096756	098846	085202	085201				127302	127309
SEV421ASP	102160	098846	085202	085201				127302	127309
SEV511	096757	098846	085202	085201				127302	127309
SEV511A	096758	098846	085202	085201				127302	127309
SEV511AU	096759	098846	085202	085201				127302	127309
SEV511VF	100838	098846	085202	085201				127302	127309
SEV521	096760	098846	085202	085201				127302	127309
SEV521AU	096761	098846	085202	085201				127302	127309
BGBSE411	102148	103430	085202	085201					
3SE1044DS	104916	105240	130176	130172				127304	
3SE1044L	104912	105240	130180	130207				127304	
3SE1054DS	104917	105240	130176	130172				127304	
3SE1054L	104913	105240	130180	130207				127304	
3SE1074DS	104914	105240	130176	130172				127304	
3SE1074L	104910	105240	130180	130207				127304	
3SE1094DS	104915	105240	130176	130172				127304	
3SE1094L	104911	105240	130180	130207				127304	
3SE514DS	104897	105240	130176	130172				127304	
3SE514L	104892	105240	130180	130207				127304	
3SE524DS	104898	105240	130176	130172				127304	
3SE524L	104893	105240	130180	130207				127304	
3SE544DS	104900	105240	130176	130172				127304	
3SE544L	104895	105240	130180	130207				127304	
3SE554DS	104901	105240	130176	130172				127304	
3SE554L	104896	105240	130180	130207				127304	

NOTE:

For a list of components in the kits refer to the pump manual.

* Previous Model Listings

Repair Kit Cross Reference

Pump Model	Pump PN	Pump Manual PN	Seal & Gasket Kit PN	Service / Overhaul Kit PN	Bearing Kit PN	"O" Ring Kit	Cutter Kit PN	BAF PN	BAF-xxxx-CV PN
3SE594DS	104899	105240	130176	130172				127304	
3SE594L	104894	105240	130180	130207				127304	
3SE744DS	104908	105240	130176	130172				127304	
3SE744L	104904	105240	130180	130207				127304	
3SE754DS	104909	105240	130176	130172				127304	
3SE754L	104905	105240	130180	130207				127304	
3SE774DS	104906	105240	130176	130172				127304	
3SE774L	104902	105240	130180	130207				127304	
3SE794DS	104907	105240	130176	130172				127304	
3SE794L	104903	105240	130180	130207				127304	
SE1044L	104890	105240	130180	130207				127302	127309
SE1054L	104891	105240	130180	130207				127302	127309
SE1074L	104888	105240	130180	130207				127302	127309
SE1094L	104889	105240	130180	130207				127302	127309
SE51	104871	105240	130180	130207				127302	127309
SE51A	104872	105240	130180	130207				127302	127309
SE51AU	104873	105240	130180	130207				127302	127309
SE51HT	104876	105240	130180	130207				127302	127309
SE51HTA	104877	105240	130180	130207				127302	127309
SE51HTAU	104878	105240	130180	130207				127302	127309
SE51-SP	105086	105240	130180	130207				127302	127309
SE52	104874	105240	130180	130207				127302	127309
SE52AU	104875	105240	130180	130207				127302	127309
SE52HT	104879	105240	130180	130207				127302	127309
SE52HTAU	104880	105240	130180	130207				127302	127309
SE544L	104882	105240	130180	130207				127302	127309
SE554L	104883	105240	130180	130207				127302	127309
SE594L	104881	105240	130180	130207				127302	127309
SE744L	104886	105240	130180	130207				127302	127309
SE754L	104887	105240	130180	130207				127302	127309
SE774L	104884	105240	130180	130207				127302	127309
SE792L	104885	105240	130180	130207				127302	127309
SED51	125553	105240DW	130180						
SED52	125554	105240DW	130180						
SED59	125555	105240DW	130180						
SED54	125556	105240DW	130180						

NOTE:

For a list of components in the kits refer to the pump manual.
 * Previous Model Listings



Repair Kit Cross Reference

Pump Model	Pump PN	Pump Manual PN	Seal & Gasket Kit PN	Service / Overhaul Kit PN	Bearing Kit PN	"O" Ring Kit	Cutter Kit PN	BAF PN	BAF-xxxx-CV PN
2SEV1022DS	104987	105241	130176	130172				127302	127309
2SEV1022L	104982	105241	130180	130207				127302	127309
2SEV1022L	104982	105241	130180	130207				127302	127309
2SEV1024DS	104940	105241	130176	130172				127302	127309
2SEV1024L	104936	105241	130180	130207				127302	127309
2SEV1042DS	104990	105241	130176	130172				127302	127309
2SEV1042L	104985	105241	130180	130207				127302	127309
2SEV1044DS	104942	105241	130176	130172				127302	127309
2SEV1044L	104938	105241	130180	130207				127302	127309
2SEV1052DS	104991	105241	130176	130172				127302	127309
2SEV1052L	104986	105241	130180	130207				127302	127309
2SEV1054DS	104943	105241	130176	130172				127302	127309
2SEV1054L	104939	105241	130180	130207				127302	127309
2SEV1092DS	104988	105241	130176	130172				127302	127309
2SEV1092L	104984	105241	130180	130207				127302	127309
2SEV1094DS	104941	105241	130176	130172				127302	127309
2SEV1094L	104937	105241	130180	130207				127302	127309
2SEV512DS	104976	105241	130176	130172				127302	127309
2SEV512L	104970	105241	130180	130207				127302	127309
2SEV514DS	104923	105241	130176	130172				127302	127309
2SEV514L	104918	105241	130180	130207				127302	127309
2SEV522DS	104977	105241	130176	130172				127302	127309
2SEV522L	104971	105241	130180	130207				127302	127309
2SEV524DS	104924	105241	130176	130172				127302	127309
2SEV524L	104919	105241	130180	130207				127302	127309
2SEV542DS	104980	105241	130176	130172				127302	127309
2SEV542L	104974	105241	130180	130207				127302	127309
2SEV544DS	104926	105241	130176	130172				127302	127309
2SEV544L	104921	105241	130180	130207				127302	127309
2SEV552DS	104981	105241	130176	130172				127302	127309
2SEV552L	104975	105241	130180	130207				127302	127309
2SEV554DS	104927	105241	130176	130172				127302	127309
2SEV554L	104922	105241	130180	130207				127302	127309

NOTE:

For a list of components in the kits refer to the pump manual.

* Previous Model Listings

Repair Kit Cross Reference

Pump Model	Pump PN	Pump Manual PN	Seal & Gasket Kit PN	Service / Overhaul Kit PN	Bearing Kit PN	"O" Ring Kit	Cutter Kit PN	BAF PN	BAF-xxxx-CV PN
2SEV592DS	104978	105241	130176	130172				127302	127309
2SEV592L	104972	105241	130180	130207				127302	127309
2SEV592L	104973	105241	130180	130207				127302	127309
2SEV594DS	104925	105241	130176	130172				127302	127309
2SEV594L	104920	105241	130180	130207				127302	127309
2SEV724DS	104932	105241	130176	130172				127302	127309
2SEV724L	104928	105241	130180	130207				127302	127309
2SEV744DS	104934	105241	130176	130172				127302	127309
2SEV744L	104930	105241	130180	130207				127302	127309
2SEV754DS	104935	105241	130176	130172				127302	127309
2SEV754L	104931	105241	130180	130207				127302	127309
2SEV794DS	104933	105241	130176	130172				127302	127309
2SEV794L	104929	105241	130180	130207				127302	127309
3SEV1022DS	105009	105241	130176	130172				127304	
3SEV1022L	105004	105241	130180	130207				127304	
3SEV1024DS	104966	105241	130176	130172				127304	
3SEV1024L	104962	105241	130180	130207				127304	
3SEV1042DS	105012	105241	130176	130172				127304	
3SEV1042L	105007	105241	130180	130207				127304	
3SEV1044DS	104968	105241	130176	130172				127304	
3SEV1044L	104964	105241	130180	130207				127304	
3SEV1052DS	105013	105241	130176	130172				127304	
3SEV1052L	105008	105241	130180	130207				127304	
3SEV1054DS	104969	105241	130176	130172				127304	
3SEV1054L	104965	105241	130180	130207				127304	
3SEV1092DS	105010	105241	130176	130172				127304	
3SEV1092L	105005	105241	130180	130207				127304	
3SEV1094DS	104967	105241	130176	130172				127304	
3SEV1094L	104963	105241	130180	130207				127304	
3SEV512DS	104998	105241	130176	130172				127304	
3SEV512L	104992	105241	130180	130207				127304	
3SEV514DS	104949	105241	130176	130172				127304	
3SEV514L	104944	105241	130180	130207				127304	

NOTE:

For a list of components in the kits refer to the pump manual.
 * Previous Model Listings



Repair Kit Cross Reference

Pump Model	Pump PN	Pump Manual PN	Seal & Gasket Kit PN	Service / Overhaul Kit PN	Bearing Kit PN	"O" Ring Kit	Cutter Kit PN	BAF PN	BAF-xxxx-CV PN
3SEV522DS	104999	105241	130176	130172				127304	
3SEV522L	104993	105241	130180	130207				127304	
3SEV524DS	104950	105241	130176	130172				127304	
3SEV524L	104945	105241	130180	130207				127304	
3SEV542DS	105002	105241	130176	130172				127304	
3SEV542L	104996	105241	130180	130207				127304	
3SEV544DS	104952	105241	130176	130172				127304	
3SEV544L	104947	105241	130180	130207				127304	
3SEV552DS	105003	105241	130176	130172				127304	
3SEV552L	104997	105241	130180	130207				127304	
3SEV554DS	104953	105241	130176	130172				127304	
3SEV554L	104948	105241	130180	130207				127304	
3SEV592DS	105000	105241	130176	130172				127304	
3SEV592L	104994	105241	130180	130207				127304	
3SEV594DS	104951	105241	130176	130172				127304	
3SEV594L	104946	105241	130180	130207				127304	
3SEV724DS	104958	105241	130176	130172				127304	
3SEV724L	104954	105241	130180	130207				127304	
3SEV744DS	104960	105241	130176	130172				127304	
3SEV744L	104956	105241	130180	130207				127304	
3SEV754DS	104961	105241	130176	130172				127304	
3SEV754L	104957	105241	130180	130207				127304	
3SEV794DS	104959	105241	130176	130172				127304	
3SEV794L	104955	105241	130180	130207				127304	
4SE1444DS	105030	105242	130176	130172				128281	
4SE1444L	105026	105242	130180	130207				128281	
4SE1454DS	105031	105242	130176	130172				128281	
4SE1454L	105027	105242	130180	130207				128281	
4SE1474DS	105028	105242	130176	130172				128281	
4SE1474L	105024	105242	130180	130207				128281	
4SE1494DS	105029	105242	130176	130172				128281	
4SE1494L	105025	105242	130180	130207				128281	

NOTE:

For a list of components in the kits refer to the pump manual.

* Previous Model Listings

Repair Kit Cross Reference

Pump Model	Pump PN	Pump Manual PN	Seal & Gasket Kit PN	Service / Overhaul Kit PN	Bearing Kit PN	"O" Ring Kit	Cutter Kit PN	BAF PN	BAF-xxxx-CV PN
4SE1944DS	105038	105242	130176	130172				128281	
4SE1944L	105034	105242	130180	130207				128281	
4SE1954DS	105039	105242	130176	130172				128281	
4SE1954L	105035	105242	130180	130207				128281	
4SE1974DS	105036	105242	130176	130172				128281	
4SE1974L	105032	105242	130180	130207				128281	
4SE1994DS	105037	105242	130176	130172				128281	
4SE1994L	105033	105242	130180	130207				128281	
4SE914DS	105019	105242	130176	130172				128281	
4SE914L	105014	105242	130180	130207				128281	
4SE924DS	105020	105242	130176	130172				128281	
4SE924L	105015	105242	130180	130207				128281	
4SE944DS	105022	105242	130176	130172				128281	
4SE944L	105017	105242	130180	130207				128281	
4SE954DS	105023	105242	130176	130172				128281	
4SE954L	105018	105242	130180	130207				128281	
4SE994DS	105021	105242	130176	130172				128281	
4SE994L	105016	105242	130180	130207				128281	
STEP1022SSA	105054B	105243	130180	130207				127302	127309
STEP512SSA	105045A	105243	130180	130207				127302	127309
STEP1022DS	105050	105243	130176	130172				127302	127309
STEP1022SS	105054	105243	130180	130207				127302	127309
STEP1042DS	105052	105243	130176	130172				127302	127309
STEP1042SS	105056	105243	130180	130207				127302	127309
STEP1052DS	105053	105243	130176	130172				127302	127309
STEP1052SS	105057	105243	130180	130207				127302	127309
STEP1092DS	105051	105243	130176	130172				127302	127309
STEP1092SS	105055	105243	130180	130207				127302	127309
STEP512DS	105040	105243	130176	130172				127302	127309
STEP512SS	105045	105243	130176	130172				127302	127309
STEP522DS	105041	105243	130176	130172				127302	127309
STEP522SS	105046	105243	130176	130172				127302	127309
STEP542DS	105043	105243	130176	130172				127302	127309
STEP542SS	105048	105243	130176	130172				127302	127309
STEP552DS	105044	105243	130176	130172				127302	127309
STEP552SS	105049	105243	130176	130172				127302	127309

NOTE:

For a list of components in the kits refer to the pump manual.
 * Previous Model Listings



Repair Kit Cross Reference

Pump Model	Pump PN	Pump Manual PN	Seal & Gasket Kit PN	Service / Overhaul Kit PN	Bearing Kit PN	"O" Ring Kit	Cutter Kit PN	BAF PN	BAF-xxxx-CV PN
STEP592DS	105042	105243	130176	130172				127302	127309
STEP592SS	105047	105243	130176	130172				127302	127309
EH1022DS	105072	105244	130176	130172				127302	127309
EH1022L	105068	105244	130180	130207				127302	127309
EH1042DS	105074	105244	130176	130172				127302	127309
EH1042L	105070	105244	130180	130207				127302	127309
EH1052DS	105075	105244	130176	130172				127302	127309
EH1052L	105071	105244	130180	130207				127302	127309
EH1092DS	105073	105244	130176	130172				127302	127309
EH1092L	105069	105244	130180	130207				127302	127309
EH1522DS	105080	105244	130176	130172				127302	127309
EH1522L	105076	105244	130180	130207				127302	127309
EH1542DS	105082	105244	130176	130172				127302	127309
EH1542L	105078	105244	130180	130207				127302	127309
EH1552DS	105083	105244	130176	130172				127302	127309
EH1552L	105079	105244	130180	130207				127302	127309
EH1592DS	105081	105244	130176	130172				127302	127309
EH1592L	105077	105244	130180	130207				127302	127309
EH512DS	105063	105244	130176	130172				127302	127309
EH512L	105058	105244	130180	130207				127302	127309
EH522DS	105064	105244	130176	130172				127302	127309
EH522L	105059	105244	130180	130207				127302	127309
EH542DS	105066	105244	130176	130172				127302	127309
EH542L	105061	105244	130180	130207				127302	127309
EH552DS	105067	105244	130176	130172				127302	127309
EH552L	105062	105244	130180	130207				127302	127309
EH592DS	105065	105244	130176	130172				127302	127309
EH592L	105060	105244	130180	130207				127302	127309
EH1522HT	105093	106991	130180	130207				127302	127309
EH1542HT	105095	106991	130180	130207				127302	127309
EH1592HT	105094	106991	130180	130207				127302	127309
EH512HT	105084	106991	130180	130207				127302	127309
EH522HT	105085	106991	130180	130207				127302	127309
3SE1524HD	107922 *	107948	130182	130209				127304	
3SE1544HD	107924 *	107948	130182	130209				127304	
3SE1594HD	107923 *	107948	130182	130209				127304	

NOTE:

For a list of components in the kits refer to the pump manual.

* Previous Model Listings (see page 37)

Repair Kit Cross Reference

Pump Model	Pump PN	Pump Manual PN	Seal & Gasket Kit PN	Service / Overhaul Kit PN	Bearing Kit PN	"O" Ring Kit	Cutter Kit PN	BAF PN	BAF-xxxx-CV PN
3SE2024HD	107926 *	107948	130182	130209				127304	
3SE2044HD	107928 *	107948	130182	130209				127304	
3SE2094HD	107927 *	107948	130182	130209				127304	
SF411	109972	108120	085202	085201					
SF511	109973	108120	085202	085201					
OGVF2022AUE	116892	108890	108303				108330		
OGVF2022AUF	110652	108890	108303				108330		
OGVF2022L	110651	108890	108303				108330		
OGVF2022M	113750	108890	108303				108330		
	116896	108890	108303				108330A		
	110650	108890	108303				108330A		
OGVH2022L	110649	108890	108303				108330A		
3SF1074L	109975	109999	107272						
SF51	109974	109999	107272						
SGVF2002L	110614	110629	113299	115946			113300	127300	127307
SGVF2022L	110609	110629	113299	115946			113300	127300	127307
SGVF2032L	110611	110629	113299	115946			113300	127300	127307
SGVF2042L	110612	110629	113299	115946			113300	127300	127307
SGVF2052L	110613	110629	113299	115946			113300	127300	127307
SGVF2062L	110610	110629	113299	115946			113300	127300	127307
SGVH2002L	110620	110629	113299	115946			113300B	127300	127307
SGVH2022L	110615	110629	113299	115946			113300B	127300	127307
SGVH2032L	110617	110629	113299	115946			113300B	127300	127307
SGVH2042L	110618	110629	113299	115946			113300B	127300	127307
SGVH2052L	110619	110629	113299	115946			113300B	127300	127307
SGVH2062L	110616	110629	113299	115946			113300B	127300	127307
3SF1524HD	110952	110954	085220	085206					
3SF2024HD	110953	110954	085220	085206					
SE51HT (Con-ED)	104876B	111124	107272					127302	127309
PGPP2022	110646	112871	108302				108321	127300	127303
PGPP2022A	112916	112871	108302				108321	127300	127303

NOTE:

For a list of components in the kits refer to the pump manual.
 * Previous Model Listings (see page 37)



Repair Kit Cross Reference

Pump Model	Pump PN	Pump Manual PN	Seal & Gasket Kit PN	Service / Overhaul Kit PN	Bearing Kit PN	"O" Ring Kit	Cutter Kit PN	BAF PN	BAF-xxxx-CV PN
SGV3032L	111609	113317	085223	115771			085225		
SGV3042L	111610	113317	085223	115771			085225		
SGV3052L	111611	113317	085223	115771			085225		
SGV3062L	111612	113317	085223	115771			085225		
SGV3072L	111608	113317	085223	115771			085225		
SGV5002L	115657	113317	118042	115772			085225		
SGV5022L	115658	113317	118042	115772			085225		
SGV5032L	111616	113317	085223	115771			085225		
SGV5042L	111617	113317	085223	115771			085225		
SGV5052L	111618	113317	085223	115771			085225		
SGV5062L	111619	113317	085223	115771			085225		
SGV7532L	111613	113317	085223	115771			085225		
SGV7542L	111614	113317	085223	115771			085225		
SGV7552L	111615	113317	085223	115771			085225		
SGPC10X4AU	113275C	114344	110477	110478			110479		
SGPC10X4-CVP	113605A	114344	110477	110478			110479		
SGPC10X4L	114934A	114344	110477	110478			110479		
70	115165	115150	115076						
71	115166	115150	115076						
125	115167	115150	115076						
126	115168	115150	115076						
126-50	115168A	115150-50	115076						
2SEV1522DS	107914	115941	130177	130173				127302	127309
2SEV1522L	104187	115941	130181	130208				127302	127309
2SEV1542DS	107916	115941	130177	130173				127302	127309
2SEV1542L	104189	115941	130181	130208				127302	127309
2SEV1552DS	107917	115941	130177	130173				127302	127309
2SEV1552L	105774	115941	130181	130208				127302	127309
2SEV1592DS	107915	115941	130177	130173				127302	127309
2SEV1592L	104188	115941	130181	130208				127302	127309
2SEV2022DS	107918	115941	130177	130173				127302	127309
2SEV2022L	104190	115941	130181	130208				127302	127309

NOTE:

For a list of components in the kits refer to the pump manual.

* Previous Model Listings

Repair Kit Cross Reference

Pump Model	Pump PN	Pump Manual PN	Seal & Gasket Kit PN	Service / Overhaul Kit PN	Bearing Kit PN	"O" Ring Kit	Cutter Kit PN	BAF PN	BAF-xxxx-CV PN
2SEV2042DS	107920	115941	130177	130173				127302	127309
2SEV2042L	104192	115941	130181	130208				127302	127309
2SEV2052DS	107921	115941	130177	130173				127302	127309
2SEV2052L	105775	115941	130181	130208				127302	127309
2SEV2092DS	107919	115941	130177	130173				127302	127309
2SEV2092L	104191	115941	130181	130208				127302	127309
PO8LA-12L	8C09D-0012-L-031	116061	089083	089094					
PO8LA-13D	8C09D-0013D-031	116061	089083	089094					
PO8LA-14X	8C09D-0014-X-031	116061	089083	089094					
PO10LA-16X	ACOAD-0016-X-031	116061	089083	089094					
SGPC1014L	117671	116452	116828	116829			116830		
SGPC10-S4AUE	116447E	116452	116828	116829			116830		
SGPC10-S4AUF	116447F	116452	116828	116829			116830		
SGPC10S4L	116447	116452	116828	116829			116830		
SGPC10S4L, CVP	116447B	116452	116828	116829			116830		
OGP2022AUE	115329	119972	116664	116665			116666		
OGP2022CC	----	119972	116664	116665			116666		
OGP2022CE	119969	119972	116664	116665			116666		
OGP2022CO	----	119972	116664	116665			116666		
OGP2022CT	----	119972	116664	116665			116666		
OGP2022L	115328	119972	116664	116665			116666		
OGVF2022CC	----	120138	108303	127238			108330		
OGVF2022CE	119973	120138	108303	127238			108330		
OGVF2022CT	----	120138	108303	127238			108330		

NOTE:

For a list of components in the kits refer to the pump manual.
 * Previous Model Listings



Repair Kit Cross Reference

Pump Model	Pump PN	Pump Manual PN	Seal & Gasket Kit PN	Service / Overhaul Kit PN	Bearing Kit PN	"O" Ring Kit	Cutter Kit PN	BAF PN	BAF-xxxx-CV PN
OGVH2022CC	----	120138	108303	127238			108330A		
OGVH2022CE	----	120138	108303	127238			108330A		
OGVH2022CT	----	120138	108303	127238			108330A		
3SHVR5075	133701	133030	133040	133054	133046				
3SHVR50N4	133702	133030	133040	133054	133046				
3SHVR5052	133703	133030	133040	133054	133046				
3SHVR75N2	133705	133030	133040	133054	133046				
3SHVR7552	133706	133030	133040	133054	133046				
3SHVR100N2	133707	133030	133040	133054	133046				
3SHVR10052	133708	133030	133040	133054	133046				
3SHMP2074	133681	133030	133040	133054	133046				
3SHMP20N4	133682	133030	133040	133054	133046				
3SHMP2054	133683	133030	133040	133054	133046				
3SHMP3074	133684	133030	133040	133054	133046				
3SHMP30N4	133685	133030	133040	133054	133046				
3SHMP3054	133686	133030	133040	133054	133046				
3SHMP5074	133687	133030	133040	133054	133046				
3SHMP50N4	133688	133030	133040	133054	133046				
3SHMP5054	133689	133030	133040	133054	133046				
3XSHVR5072	133828		133040	133054	133046				
3XSHVR50N2	133829		133040	133054	133046				
3XSHVR5052	133830		133040	133054	133046				
3XSHVR75N2	133832		133040	133054	133046				
3XSHVR7552	133833		133040	133054	133046				
3XSHVR100N2	133834		133040	133054	133046				
3XSHVR10052	133835		133040	133054	133046				
3XSHMP2074	133819		133040	133054	133046				
3XSHMP20N4	133820		133040	133054	133046				
3XSHMP2054	133821		133040	133054	133046				
3XSHMP3074	133822		133040	133054	133046				
3XSHMP30N4	133823		133040	133054	133046				
3XSHMP3054	133824		133040	133054	133046				

NOTE:

For a list of components in the kits refer to the pump manual.

* Previous Model Listings

Repair Kit Cross Reference

Pump Model	Pump PN	Pump Manual PN	Seal & Gasket Kit PN	Service / Overhaul Kit PN	Bearing Kit PN	"O" Ring Kit	Cutter Kit PN	BAF PN	BAF-xxxx-CV PN
3XSHMP5074	133825		133040	133054	133046				
3XSHMP50N4	133826		133040	133054	133046				
3XSHMP5054	133827		133040	133054	133046				
4SHVA75N2	133650	133030	133040	133054	133046				
4SHVA7552	133651	133030	133040	133054	133046				
4SHVA100N2	133652	133030	133040	133054	133046				
4SHVA10052	133653	133030	133040	133054	133046				
4SHVB75N2	133655	133030	133040	133054	133046				
4SHVB7552	133656	133030	133040	133054	133046				
4SHVB100N2	133657	133030	133040	133054	133046				
4SHVB10052	133658	133030	133040	133054	133046				
4SHMS3074	133659	133030	133040	133054	133046				
4SHMS30N4	133660	133030	133040	133054	133046				
4SHMS3054	133661	133030	133040	133054	133046				
4SHMS5074	133662	133030	133040	133054	133046				
4SHMS50N4	133663	133030	133040	133054	133046				
4SHMS5054	133664	133030	133040	133054	133046				
4SHMS75N4	133666	133030	133040	133054	133046				
4SHMS7554	133667	133030	133040	133054	133046				
4SHMC5074	133641	133030	133040	133054	133046				
4SHMC50N4	133642	133030	133040	133054	133046				
4SHMC5054	133643	133030	133040	133054	133046				
4SHMC75N4	133645	133030	133040	133054	133046				

NOTE:

For a list of components in the kits refer to the pump manual.
 * Previous Model Listings



Repair Kit Cross Reference

Pump Model	Pump PN	Pump Manual PN	Seal & Gasket Kit PN	Service / Overhaul Kit PN	Bearing Kit PN	"O" Ring Kit	Cutter Kit PN	BAF PN	BAF-xxxx-CV PN
4SHMC7554	133646	133030	133040	133054	133046				
4SHMC100N4	133647	133030	133040	133054	133046				
4SHMC10054	133648	133030	133040	133054	133046				
4SHDF3074	133670	133030	133040	133054	133046				
4SHDF30N4	133671	133030	133040	133054	133046				
4SHDF3054	133672	133030	133040	133054	133046				
4SHDF5074	133673	133030	133040	133054	133046				
4SHDF50N4	133674	133030	133040	133054	133046				
4SHDF5054	133675	133030	133040	133054	133046				
4SHDF75N4	133677	133030	133040	133054	133046				
4SHDF7554	133678	133030	133040	133054	133046				
4SHDF100N4	133679	133030	133040	133054	133046				
4SHDF10054	133680	133030	133040	133054	133046				
4SHDG5074	133633	133030	133040	133054	133046				
4SHDG50N4	133634	133030	133040	133054	133046				
4SHDG5054	133635	133030	133040	133054	133046				
4SHDG75N4	133637	133030	133040	133054	133046				
4SHDG7554	133638	133030	133040	133054	133046				
4SHDG100N4	133639	133030	133040	133054	133046				
4SHDG10054	133640	133030	133040	133054	133046				
4SHVA150N2	127446	125508	132120A	132119	132118A			128281	
4SHVA15052	127447	125508	132120A	132119	132118A			128281	
4SHVA20082	127448	125508	132120A	132119	132118A			128281	
4SHVA20052	127449	125508	132120A	132119	132118A			128281	
4SHVA25042	127450	125508	132120A	132119	132118A			128281	
4SHVA25052	127451	125508	132120A	132119	132118A			128281	
4SHVA30042	127452	125508	132120A	132119	132118A			128281	
4SHVA30052	127453	125508	132120A	132119	132118A			128281	
4SHVB150N2	127494	125508	132120A	132119	132118A			128281	
4SHVB15052	127495	125508	132120A	132119	132118A			128281	
4SHVB20082	127496	125508	132120A	132119	132118A			128281	
4SHVB20052	127497	125508	132120A	132119	132118A			128281	
4SHVB25042	127498	125508	132120A	132119	132118A			128281	

NOTE:

For a list of components in the kits refer to the pump manual.

* Previous Model Listings

Repair Kit Cross Reference

Pump Model	Pump PN	Pump Manual PN	Seal & Gasket Kit PN	Service / Overhaul Kit PN	Bearing Kit PN	"O" Ring Kit	Cutter Kit PN	BAF PN	BAF-xxxx-CV PN
4SHVB25052	127499	125508	132120A	132119	132118A			128281	
4SHVB30042	127500	125508	132120A	132119	132118A			128281	
4SHVB30052	127501	125508	132120A	132119	132118A			128281	
4SHMC150N4	130030	125508	132120A	132119	132118A			128281	
4SHMC15054	130031	125508	132120A	132119	132118A			128281	
4SHMD150N4	130032	125508	132120A	132119	132118A			128281	
4SHMD15054	130033	125508	132120A	132119	132118A			128281	
4SHMD20084	130034	125508	132120A	132119	132118A			128281	
4SHMD20054	130035	125508	132120A	132119	132118A			128281	
4SHMD25044	130037	125508	132120A	132119	132118A			128281	
4SHMD25054	130038	125508	132120A	132119	132118A			128281	
4SHMD30044	130040	125508	132120A	132119	132118A			128281	
4SHMD30054	130041	125508	132120A	132119	132118A			128281	
4SHDG150N4	130174	125508	132120A	132119	132118A			128281	
4SHDG15054	130175	125508	132120A	132119	132118A			128281	
4SHDG20084	130177	125508	132120A	132119	132118A			128281	
4SHDG20054	130178	125508	132120A	132119	132118A			128281	
4SHDI20084	130982	125508	132120A	132119	132118A			128281	
4SHDI20054	130983	125508	132120A	132119	132118A			128281	
4SHDI25044	130597	125508	132120A	132119	132118A			128281	
4SHDI25054	130598	125508	132120A	132119	132118A			128281	
4SHDI30044	130600	125508	132120A	132119	132118A			128281	
4SHDI30054	130601	125508	132120A	132119	132118A			128281	
4SHVA20062	130984	130642	132120B	132119	132118B			128281	
4SHVA25092	127459	130642	132120B	132119	132118B			128281	
4SHVA30092	130074	130642	132120B	132119	132118B			128281	
4SHVA40032	127454	130642	132120B	132119	132118B			128281	
4SHVA40042	127455	130642	132120B	132119	132118B			128281	
4SHVA40052	127456	130642	132120B	132119	132118B			128281	
4SHVB20062	130985	130642	132120B	132119	132118B			128281	
4SHVB25092	127507	130642	132120B	132119	132118B			128281	
4SHVB30092	130075	130642	132120B	132119	132118B			128281	
4SHVB40032	127502	130642	132120B	132119	132118B			128281	
4SHVB40042	127503	130642	132120B	132119	132118B			128281	

NOTE:

For a list of components in the kits refer to the pump manual.
 * Previous Model Listings



Repair Kit Cross Reference

Pump Model	Pump PN	Pump Manual PN	Seal & Gasket Kit PN	Service / Overhaul Kit PN	Bearing Kit PN	"O" Ring Kit	Cutter Kit PN	BAF PN	BAF-xxxx-CV PN
4SHVB40052	127504	130642	132120B	132119	132118B			128281	
4SHVB50042	127505	130642	132120B	132119	132118B			128281	
4SHVB50052	127506	130642	132120B	132119	132118B			128281	
4SHMD20064	130976	130642	132120B	132119	132118B			128281	
4SHMD25094	130036	130642	132120B	132119	132118B			128281	
4SHMD30094	130039	130642	132120B	132119	132118B			128281	
4SHMD40034	130042	130642	132120B	132119	132118B			128281	
4SHMD40044	130043	130642	132120B	132119	132118B			128281	
4SHMD40054	130044	130642	132120B	132119	132118B			128281	
4SHME40034	130589	130642	132120B	132119	132118B			128281	
4SHME40044	130590	130642	132120B	132119	132118B			128281	
4SHME40054	130591	130642	132120B	132119	132118B			128281	
4SHME50044	130592	130642	132120B	132119	132118B			128281	
4SHME50054	130593	130642	132120B	132119	132118B			128281	
4SHME60044	130594	130642	132120B	132119	132118B			128281	
4SHME60054	130595	130642	132120B	132119	132118B			128281	
4SHDI20064	130981	130642	132120B	132119	132118B			128281	
4SHDI25094	130596	130642	132120B	132119	132118B			128281	
4SHDI30094	130599	130642	132120B	132119	132118B			128281	
4SHDI40034	130602	130642	132120B	132119	132118B			128281	
4SHDI40044	130603	130642	132120B	132119	132118B			128281	
4SHDI40054	130604	130642	132120B	132119	132118B			128281	
4SHDI50044	130605	130642	132120B	132119	132118B			128281	

NOTE:

For a list of components in the kits refer to the pump manual.

* Previous Model Listings

Repair Kit Cross Reference

Pump Model	Pump PN	Pump Manual PN	Seal & Gasket Kit PN	Service / Overhaul Kit PN	Bearing Kit PN	"O" Ring Kit	Cutter Kit PN	BAF PN	BAF-xxxx-CV PN
4SHDI50054	130606	130642	132120B	132119	132118B			128281	
4SHDI60054	130607	130642	132120B	132119	132118B			128281	
4SHDI60054	130608	130642	132120B	132119	132118B			128281	
4XSHV75N2	133691		133040	133054	133046				
4XSHV7552	133692		133040	133054	133046				
4XSHV100N2	133693		133040	133054	133046				
4XSHV10052	133694		133040	133054	133046				
4XSHV75N2	133696		133040	133054	133046				
4XSHV7552	133697		133040	133054	133046				
4XSHV100N2	133698		133040	133054	133046				
4XSHV10052	133699		133040	133054	133046				
4XSHMS3074	133799		133040	133054	133046				
4XSHMS30N4	133800		133040	133054	133046				
4XSHMS3054	133801		133040	133054	133046				
4XSHMS5074	133802		133040	133054	133046				
4XSHMS50N4	133803		133040	133054	133046				
4XSHMS5054	133804		133040	133054	133046				
4XSHMS75N4	133806		133040	133054	133046				
4XSHMS7554	133807		133040	133054	133046				
4XSHMC5074	133709		133040	133054	133046				
4XSHMC50N4	133710		133040	133054	133046				
4XSHMC5054	133711		133040	133054	133046				
4XSHMC75N4	133712		133040	133054	133046				
4XSHMC7554	133713		133040	133054	133046				
4XSHMC100N4	133714		133040	133054	133046				
4XSHMC10054	133715		133040	133054	133046				
4XSHDF3074	133808		133040	133054	133046				
4XSHDF30N4	133809		133040	133054	133046				
4XSHDF3054	133810		133040	133054	133046				
4XSHDF5074	133811		133040	133054	133046				
4XSHDF50N4	133812		133040	133054	133046				
4XSHDF5054	133813		133040	133054	133046				
4XSHDF75N4	133815		133040	133054	133046				

NOTE:

For a list of components in the kits refer to the pump manual.
 * Previous Model Listings



Repair Kit Cross Reference

Pump Model	Pump PN	Pump Manual PN	Seal & Gasket Kit PN	Service / Overhaul Kit PN	Bearing Kit PN	"O" Ring Kit	Cutter Kit PN	BAF PN	BAF-xxxx-CV PN
4XSHDF7554	133816		133040	133054	133046				
4XSHDF100N4	133817		133040	133054	133046				
4XSHDF10054	133818		133040	133054	133046				
4XSHDG5074	133271		133040	133054	133046				
4XSHDG50N4	133272		133040	133054	133046				
4XSHDG5054	133273		133040	133054	133046				
4XSHDG75N4	133276		133040	133054	133046				
4XSHDG7554	133277		133040	133054	133046				
4XSHDG100N4	133278		133040	133054	133046				
4XSHDG10054	133279		133040	133054	133046				
4XSHVA150N2	127426	125854	132120A	132119	132118A			128281	
4XSHVA15052	127427	125854	132120A	132119	132118A			128281	
4XSHVA20082	127428	125854	132120A	132119	132118A			128281	
4XSHVA20052	127429	125854	132120A	132119	132118A			128281	
4XSHVA25042	127430	125854	132120A	132119	132118A			128281	
4XSHVA25052	127431	125854	132120A	132119	132118A			128281	
4XSHVA30042	127432	125854	132120A	132119	132118A			128281	
4XSHVA30052	127433	125854	132120A	132119	132118A			128281	
4XSHVB150N2	127476	125854	132120A	132119	132118A			128281	
4XSHVB15052	127477	125854	132120A	132119	132118A			128281	
4XSHVB20082	127478	125854	132120A	132119	132118A			128281	
4XSHVB20052	127479	125854	132120A	132119	132118A			128281	
4XSHVB25042	127480	125854	132120A	132119	132118A			128281	
4XSHVB25052	127481	125854	132120A	132119	132118A			128281	
4XSHVB30042	127482	125854	132120A	132119	132118A			128281	
4XSHVB30052	127483	125854	132120A	132119	132118A			128281	
4XSHMC150N4	130051	125854	132120A	132119	132118A			128281	
4XSHMC15054	130052	125854	132120A	132119	132118A			128281	
4XSHMD150N4	130609	125854	132120A	132119	132118A			128281	
4XSHMD15054	130610	125854	132120A	132119	132118A			128281	
4XSHMD20084	130611	125854	132120A	132119	132118A			128281	
4XSHMD20054	130612	125854	132120A	132119	132118A			128281	
4XSHMD25044	130614	125854	132120A	132119	132118A			128281	

NOTE:

For a list of components in the kits refer to the pump manual.

* Previous Model Listings

Repair Kit Cross Reference

Pump Model	Pump PN	Pump Manual PN	Seal & Gasket Kit PN	Service / Overhaul Kit PN	Bearing Kit PN	"O" Ring Kit	Cutter Kit PN	BAF PN	BAF-xxxx-CV PN
4XSHMD25054	130615	125854	132120A	132119	132118A			128281	
4XSHMD30044	130617	125854	132120A	132119	132118A			128281	
4XSHMD30054	130618	125854	132120A	132119	132118A			128281	
4XSHDG150N4	132608	125854	132120A	132119	132118A			128281	
4XSHDG15054	132609	125854	132120A	132119	132118A			128281	
4XSHDG20084	132610	125854	132120A	132119	132118A			128281	
4XSHDG20054	132611	125854	132120A	132119	132118A			128281	
4XSHDI20084	130014	125854	132120A	132119	132118A			128281	
4XSHDI20054	130015	125854	132120A	132119	132118A			128281	
4XSHDI25044	130630	125854	132120A	132119	132118A			128281	
4XSHDI25054	130631	125854	132120A	132119	132118A			128281	
4XSHDI30044	130633	125854	132120A	132119	132118A			128281	
4XSHDI30054	130634	125854	132120A	132119	132118A			128281	
4XSHVA20062	131010	130837	132120B	132119	132118B			128281	
4XSHVA25092	127439	130837	132120B	132119	132118B			128281	
4XSHVA30092	130053	130837	132120B	132119	132118B			128281	
4XSHVA40032	127434	130837	132120B	132119	132118B			128281	
4XSHVA40042	127435	130837	132120B	132119	132118B			128281	
4XSHVA40052	127436	130837	132120B	132119	132118B			128281	
4XSHVB20062	131011	130837	132120B	132119	132118B			128281	
4XSHVB25092	127489	130837	132120B	132119	132118B			128281	
4XSHVB30092	130054	130837	132120B	132119	132118B			128281	
4XSHVB40032	127484	130837	132120B	132119	132118B			128281	
4XSHVB40042	127485	130837	132120B	132119	132118B			128281	
4XSHVB40052	127486	130837	132120B	132119	132118B			128281	
4XSHVB50042	127487	130837	132120B	132119	132118B			128281	
4XSHVB50052	127488	130837	132120B	132119	132118B			128281	
4XSHMD20064	131012	130837	132120B	132119	132118B			128281	
4XSHMD25094	130613	130837	132120B	132119	132118B			128281	

NOTE:

For a list of components in the kits refer to the pump manual.
 * Previous Model Listings



Repair Kit Cross Reference

Pump Model	Pump PN	Pump Manual PN	Seal & Gasket Kit PN	Service / Overhaul Kit PN	Bearing Kit PN	"O" Ring Kit	Cutter Kit PN	BAF PN	BAF-xxxx-CV PN
4XSHMD30094	130616	130837	132120B	132119	132118B			128281	
4XSHMD40034	130619	130837	132120B	132119	132118B			128281	
4XSHMD40044	130620	130837	132120B	132119	132118B			128281	
4XSHMD40054	130621	130837	132120B	132119	132118B			128281	
4XSHME40034	130622	130837	132120B	132119	132118B			128281	
4XSHME40044	130623	130837	132120B	132119	132118B			128281	
4XSHME40054	130624	130837	132120B	132119	132118B			128281	
4XSHME50044	130625	130837	132120B	132119	132118B			128281	
4XSHME50054	130626	130837	132120B	132119	132118B			128281	
4XSHME60044	130627	130837	132120B	132119	132118B			128281	
4XSHME60054	130628	130837	132120B	132119	132118B			128281	
4XSHDI20064	131013	130837	132120B	132119	132118B			128281	
4XSHDI25094	130629	130837	132120B	132119	132118B			128281	
4XSHDI30094	130632	130837	132120B	132119	132118B			128281	
4XSHDI40034	130635	130837	132120B	132119	132118B			128281	
4XSHDI40044	130636	130837	132120B	132119	132118B			128281	
4XSHDI40054	130637	130837	132120B	132119	132118B			128281	
4XSHDI50044	130638	130837	132120B	132119	132118B			128281	
4XSHDI50054	130639	130837	132120B	132119	132118B			128281	
4XSHDI60044	130640	130837	132120B	132119	132118B			128281	
4XSHDI60054	130641	130837	132120B	132119	132118B			128281	
6SHVL20084	132258	125508	132120A	132119	132118A				
6SHVL20054	132259	125508	132120A	132119	132118A				
6SHVL25044	132261	125508	132120A	132119	132118A				
6SHVL25054	132262	125508	132120A	132119	132118A				
6SHVL30044	132264	125508	132120A	132119	132118A				
6SHVL30054	132265	125508	132120A	132119	132118A				
6SHVL75N6	132273	125508	132120A	132119	132118A				
6SHVL7556	132274	125508	132120A	132119	132118A				
6SHVL100N6	132275	125508	132120A	132119	132118A				
6SHVL10056	132276	125508	132120A	132119	132118A				
6SHVL150N6	132277	125508	132120A	132119	132118A				

NOTE:

For a list of components in the kits refer to the pump manual.

* Previous Model Listings

Repair Kit Cross Reference

Pump Model	Pump PN	Pump Manual PN	Seal & Gasket Kit PN	Service / Overhaul Kit PN	Bearing Kit PN	"O" Ring Kit	Cutter Kit PN	BAF PN	BAF-xxxx-CV PN
6SHVL15056	132278	125508	132120A	132119	132118A				
6SHVL20046	132280	125508	132120A	132119	132118A				
6SHVL20056	132281	125508	132120A	132119	132118A				
6SHMN150N4	132186	125508	132120A	132119	132118A				
6SHMN15054	132187	125508	132120A	132119	132118A				
6SHMN20084	132189	125508	132120A	132119	132118A				
6SHMN20054	132190	125508	132120A	132119	132118A				
6SHMN25044	132192	125508	132120A	132119	132118A				
6SHMN25054	132193	125508	132120A	132119	132118A				
6SHMN75N6	132204	125508	132120A	132119	132118A				
6SHMN7556	132205	125508	132120A	132119	132118A				
6SHMH30044	132195	125508	132120A	132119	132118A				
6SHMH30054	132196	125508	132120A	132119	132118A				
6SHMH100N6	132206	125508	132120A	132119	132118A				
6SHMH10056	132207	125508	132120A	132119	132118A				
6SHMH150N6	132176	125508	132120A	132119	132118A				
6SHMH15056	132181	125508	132120A	132119	132118A				
6SHMJ150N6	132208	125508	132120A	132119	132118A				
6SHMJ15056	132209	125508	132120A	132119	132118A				
6SHMJ20046	132211	125508	132120A	132119	132118A				
6SHMJ20056	132212	125508	132120A	132119	132118A				
6SHDK25044	132225	125508	132120A	132119	132118A				
6SHDK25054	132226	125508	132120A	132119	132118A				
6SHDK30044	132228	125508	132120A	132119	132118A				
6SHDK30054	132229	125508	132120A	132119	132118A				
6SHDK75N6	132237	125508	132120A	132119	132118A				
6SHDK7556	132238	125508	132120A	132119	132118A				
6SHDK100N6	132239	125508	132120A	132119	132118A				
6SHDK10056	132240	125508	132120A	132119	132118A				
6SHDK150N6	132241	125508	132120A	132119	132118A				

NOTE:

For a list of components in the kits refer to the pump manual.
 * Previous Model Listings



Repair Kit Cross Reference

Pump Model	Pump PN	Pump Manual PN	Seal & Gasket Kit PN	Service / Overhaul Kit PN	Bearing Kit PN	"O" Ring Kit	Cutter Kit PN	BAF PN	BAF-xxxx-CV PN
6SHDK15056	132242	125508	132120A	132119	132118A				
6SHDK20046	132244	125508	132120A	132119	132118A				
6SHDK20056	132245	125508	132120A	132119	132118A				
6SHVL20064	132257	130642	132120B	132119	132118B				
6SHVL25094	132260	130642	132120B	132119	132118B				
6SHVL30094	132263	130642	132120B	132119	132118B				
6SHVL40034	132266	130642	132120B	132119	132118B				
6SHVL40044	132267	130642	132120B	132119	132118B				
6SHVL40054	132268	130642	132120B	132119	132118B				
6SHVL50044	132269	130642	132120B	132119	132118B				
6SHVL50054	132270	130642	132120B	132119	132118B				
6SHVL60044	132271	130642	132120B	132119	132118B				
6SHVL60054	132272	130642	132120B	132119	132118B				
6SHVL20096	132279	130642	132120B	132119	132118B				
6SHVL25096	132282	130642	132120B	132119	132118B				
6SHVL25046	132283	130642	132120B	132119	132118B				
6SHVL25056	132284	130642	132120B	132119	132118B				
6SHVL30096	132285	130642	132120B	132119	132118B				
6SHVL30046	132286	130642	132120B	132119	132118B				
6SHVL30056	132287	130642	132120B	132119	132118B				
6SHVL40036	132288	130642	132120B	132119	132118B				
6SHVL40046	132289	130642	132120B	132119	132118B				
6SHVL40056	132290	130642	132120B	132119	132118B				
6SHMN20064	132188	130642	132120B	132119	132118B				
6SHMN25094	132191	130642	132120B	132119	132118B				
6SHMH30094	132194	130642	132120B	132119	132118B				
6SHMH40034	132197	130642	132120B	132119	132118B				
6SHMH40044	132198	130642	132120B	132119	132118B				
6SHMH40054	132199	130642	132120B	132119	132118B				
6SHMH50044	132179	130642	132120B	132119	132118B				
6SHMH50054	132180	130642	132120B	132119	132118B				
6SHMJ50054	132200	130642	132120B	132119	132118B				
6SHMJ50054	132201	130642	132120B	132119	132118B				
6SHMJ60044	132202	130642	132120B	132119	132118B				
6SHMJ60054	132203	130642	132120B	132119	132118B				

NOTE:

For a list of components in the kits refer to the pump manual.

* Previous Model Listings

Repair Kit Cross Reference

Pump Model	Pump PN	Pump Manual PN	Seal & Gasket Kit PN	Service / Overhaul Kit PN	Bearing Kit PN	"O" Ring Kit	Cutter Kit PN	BAF PN	BAF-xxxx-CV PN
6SHMJ20096	132210	130642	132120B	132119	132118B				
6SHMJ25096	132213	130642	132120B	132119	132118B				
6SHMJ25046	132214	130642	132120B	132119	132118B				
6SHMJ25056	132215	130642	132120B	132119	132118B				
6SHDK25096	132224	130642	132120B	132119	132118B				
6SHDK30094	132227	130642	132120B	132119	132118B				
6SHDK40034	132230	130642	132120B	132119	132118B				
6SHDK40044	132231	130642	132120B	132119	132118B				
6SHDK40054	132232	130642	132120B	132119	132118B				
6SHDK50044	132233	130642	132120B	132119	132118B				
6SHDK50054	132234	130642	132120B	132119	132118B				
6SHDK60044	132235	130642	132120B	132119	132118B				
6SHDK60054	132236	130642	132120B	132119	132118B				
6SHDK20096	132243	130642	132120B	132119	132118B				
6SHDK25096	132246	130642	132120B	132119	132118B				
6SHDK25046	132247	130642	132120B	132119	132118B				
6SHDK25056	132248	130642	132120B	132119	132118B				
6SHDK30096	132249	130642	132120B	132119	132118B				
6SHDK30046	132250	130642	132120B	132119	132118B				
6SHDK30056	132251	130642	132120B	132119	132118B				
6SHDK40036	132252	130642	132120B	132119	132118B				
6SHDK40046	132253	130642	132120B	132119	132118B				
6SHDK40056	132254	130642	132120B	132119	132118B				
6XSHVL20084	132674	125854	132120A	132119	132118A				
6XSHVL20054	132675	125854	132120A	132119	132118A				
6XSHVL25044	132677	125854	132120A	132119	132118A				
6XSHVL25054	132678	125854	132120A	132119	132118A				
6XSHVL30044	132680	125854	132120A	132119	132118A				
6XSHVL30054	132681	125854	132120A	132119	132118A				
6XSHVL75N6	132689	125854	132120A	132119	132118A				
6XSHVL7556	132690	125854	132120A	132119	132118A				
6XSHVL100N6	132691	125854	132120A	132119	132118A				
6XSHVL10056	132692	125854	132120A	132119	132118A				
6XSHVL150N6	132693	125854	132120A	132119	132118A				

NOTE:

For a list of components in the kits refer to the pump manual.
 * Previous Model Listings



A Crane Co. Company

PUMPS & SYSTEMS

USA: (937) 778-8947 • Canada: (905) 457-6223 • International: (937) 615-3598

SECTION	RP-KIT
PAGE	31
DATE	7/12

Repair Kit Cross Reference

Pump Model	Pump PN	Pump Manual PN	Seal & Gasket Kit PN	Service / Overhaul Kit PN	Bearing Kit PN	"O" Ring Kit	Cutter Kit PN	BAF PN	BAF-xxxx-CV PN
6XSHVL15056	132694	125854	132120A	132119	132118A				
6XSHVL20046	132696	125854	132120A	132119	132118A				
6XSHVL20056	132697	125854	132120A	132119	132118A				
6XSHMN150N4	132612	125854	132120A	132119	132118A				
6XSHMN15054	132613	125854	132120A	132119	132118A				
6XSHMN20084	132615	125854	132120A	132119	132118A				
6XSHMN20054	132616	125854	132120A	132119	132118A				
6XSHMN25044	132618	125854	132120A	132119	132118A				
6XSHMN25054	132619	125854	132120A	132119	132118A				
6XSHMN75N6	132630	125854	132120A	132119	132118A				
6XSHMN7556	132631	125854	132120A	132119	132118A				
6XSHMH30044	132621	125854	132120A	132119	132118A				
6XSHMH30054	132622	125854	132120A	132119	132118A				
6XSHMH100N6	132632	125854	132120A	132119	132118A				
6XSHMH10056	132633	125854	132120A	132119	132118A				
6XSHMH150N6	132805	125854	132120A	132119	132118A				
6XSHMH15056	132806	125854	132120A	132119	132118A				
6XSHMJ150N6	132634	125854	132120A	132119	132118A				
6XSHMJ15056	132635	125854	132120A	132119	132118A				
6XSHMJ20046	132637	125854	132120A	132119	132118A				
6XSHMJ20056	132638	125854	132120A	132119	132118A				
6XSHDK25044	132643	125854	132120A	132119	132118A				
6XSHDK25054	132644	125854	132120A	132119	132118A				
6XSHDK30044	132646	125854	132120A	132119	132118A				
6XSHDK30054	132647	125854	132120A	132119	132118A				
6XSHDK75N6	132655	125854	132120A	132119	132118A				
6XSHDK7556	132656	125854	132120A	132119	132118A				
6XSHDK100N6	132657	125854	132120A	132119	132118A				
6XSHDK10056	132658	125854	132120A	132119	132118A				
6XSHDK150N6	132659	125854	132120A	132119	132118A				

NOTE:

For a list of components in the kits refer to the pump manual.

* Previous Model Listings

Repair Kit Cross Reference

Pump Model	Pump PN	Pump Manual PN	Seal & Gasket Kit PN	Service / Overhaul Kit PN	Bearing Kit PN	"O" Ring Kit	Cutter Kit PN	BAF PN	BAF-xxxx-CV PN
6XSHDK15056	132660	125854	132120A	132119	132118A				
6XSHDK20046	132662	125854	132120A	132119	132118A				
6XSHDK20056	132663	125854	132120A	132119	132118A				
6XSHVL20064	132673	130837	132120B	132119	132118B				
6XSHVL25044	132677	130837	132120B	132119	132118B				
6XSHVL30094	132679	130837	132120B	132119	132118B				
6XSHVL40034	132682	130837	132120B	132119	132118B				
6XSHVL40044	132683	130837	132120B	132119	132118B				
6XSHVL40054	132684	130837	132120B	132119	132118B				
6XSHVL50044	132685	130837	132120B	132119	132118B				
6XSHVL50054	132686	130837	132120B	132119	132118B				
6XSHVL60044	132687	130837	132120B	132119	132118B				
6XSHVL60054	132688	130837	132120B	132119	132118B				
6XSHVL20096	132695	130837	132120B	132119	132118B				
6XSHVL25096	132698	130837	132120B	132119	132118B				
6XSHVL25046	132699	130837	132120B	132119	132118B				
6XSHVL25056	132700	130837	132120B	132119	132118B				
6XSHVL30096	132701	130837	132120B	132119	132118B				
6XSHVL30046	132702	130837	132120B	132119	132118B				
6XSHVL30056	132703	130837	132120B	132119	132118B				
6XSHVL40036	132704	130837	132120B	132119	132118B				
6XSHVL40046	132705	130837	132120B	132119	132118B				
6XSHVL40056	132706	130837	132120B	132119	132118B				
6XSHMN20064	132614	130837	132120B	132119	132118B				
6XSHMN25094	132617	130837	132120B	132119	132118B				
6XSHMH30094	132620	130837	132120B	132119	132118B				
6XSHMH40034	132623	130837	132120B	132119	132118B				

NOTE:

For a list of components in the kits refer to the pump manual.
 * Previous Model Listings



A Crane Co. Company

PUMPS & SYSTEMS

USA: (937) 778-8947 • Canada: (905) 457-6223 • International: (937) 615-3598

SECTION	RP-KIT
PAGE	33
DATE	7/12

Repair Kit Cross Reference

Pump Model	Pump PN	Pump Manual PN	Seal & Gasket Kit PN	Service / Overhaul Kit PN	Bearing Kit PN	"O" Ring Kit	Cutter Kit PN	BAF PN	BAF-xxxx-CV PN
6XSHMH40044	132624	130837	132120B	132119	132118B				
6XSHMH40054	132625	130837	132120B	132119	132118B				
6XSHMH50044	132803	130837	132120B	132119	132118B				
6XSHMH50054	132804	130837	132120B	132119	132118B				
6XSHMJ50044	132626	130837	132120B	132119	132118B				
6XSHMJ50054	132627	130837	132120B	132119	132118B				
6XSHMJ60044	132628	130837	132120B	132119	132118B				
6XSHMJ60054	132629	130837	132120B	132119	132118B				
6XSHMJ20096	132636	130837	132120B	132119	132118B				
6XSHMJ25096	132639	130837	132120B	132119	132118B				
6XSHMJ25046	132640	130837	132120B	132119	132118B				
6XSHMJ25056	132641	130837	132120B	132119	132118B				
6XSHDK25094	132642	130837	132120B	132119	132118B				
6XSHDK30094	132645	130837	132120B	132119	132118B				
6XSHDK40034	132648	130837	132120B	132119	132118B				
6XSHDK40044	132649	130837	132120B	132119	132118B				
6XSHDK40054	132650	130837	132120B	132119	132118B				
6XSHDK50044	132651	130837	132120B	132119	132118B				
6XSHDK50054	132652	130837	132120B	132119	132118B				
6XSHDK60044	132653	130837	132120B	132119	132118B				
6XSHDK60054	132654	130837	132120B	132119	132118B				
6XSHDK20096	132661	130837	132120B	132119	132118B				
6XSHDK25096	132664	130837	132120B	132119	132118B				
6XSHDK25046	132665	130837	132120B	132119	132118B				
6XSHDK25056	132666	130837	132120B	132119	132118B				
6XSHDK30096	132667	130837	132120B	132119	132118B				
6XSHDK30046	132668	130837	132120B	132119	132118B				
6XSHDK30056	132669	130837	132120B	132119	132118B				

NOTE:

For a list of components in the kits refer to the pump manual.

* Previous Model Listings

Repair Kit Cross Reference

Pump Model	Pump PN	Pump Manual PN	Seal & Gasket Kit PN	Service / Overhaul Kit PN	Bearing Kit PN	"O" Ring Kit	Cutter Kit PN	BAF PN	BAF-xxxx-CV PN
6XSHDK40036	132670	130837	132120B	132119	132118B				
6XSHDK40046	132671	130837	132120B	132119	132118B				
6XSHDK40056	132672	130837	132120B	132119	132118B				
8SHTM25096	132291	130642	132120B	132119	132118B				
8SHTM25046	132292	130642	132120B	132119	132118B				
8SHTM25056	132293	130642	132120B	132119	132118B				
8SHTM30096	132294	130642	132120B	132119	132118B				
8SHTM30046	132295	130642	132120B	132119	132118B				
8SHTM30056	132296	130642	132120B	132119	132118B				
8SHTM40036	132297	130642	132120B	132119	132118B				
8SHTM40046	132298	130642	132120B	132119	132118B				
8SHTM40056	132299	130642	132120B	132119	132118B				
8XSHTM25096	132707	130837	132120B	132119	132118B				
8XSHTM25046	132708	130837	132120B	132119	132118B				
8XSHTM25056	132709	130837	132120B	132119	132118B				
8XSHTM30096	132710	130837	132120B	132119	132118B				
8XSHTM30046	132711	130837	132120B	132119	132118B				
8XSHTM30056	132712	130837	132120B	132119	132118B				
8XSHTM40036	132713	130837	132120B	132119	132118B				
8XSHTM40046	132714	130837	132120B	132119	132118B				
8XSHTM40056	132715	130837	132120B	132119	132118B				

NOTE:

For a list of components in the kits refer to the pump manual.
 * Previous Model Listings



Repair Kit Cross Reference

Pump Model	Pump PN	Pump Manual PN	Seal & Gasket Kit PN	Service / Overhaul Kit PN	Bearing Kit PN	"O" Ring Kit	Cutter Kit PN	BAF PN	BAF-xxxx-CV PN
4SE1926L	133159	133406	130178	130174					
4SE1996L	133160	133406	130178	130174					
4SE1946L	133161	133406	130178	130174					
4SE1956L	133162	133406	130178	130174					
4SE2826L	133163	133406	130178	130174					
4SE2896L	133164	133406	130178	130174					
4SE2846L	133165	133406	130178	130174					
4SE2856L	133166	133406	130178	130174					
4SE2824L	133125	133406	130178	130174					
4SE2894L	133141	133406	130178	130174					
4SE2844L	133142	133406	130178	130174					
4SE2854L	133144	133406	130178	130174					
4SE3724L	133145	133406	130178	130174					
4SE3794L	133146	133406	130178	130174					
4SE3744L	133147	133406	130178	130174					
4SE3754L	133148	133406	130178	130174					
4SE5024L	133149	133406	130178	130174					
4SE5094L	133150	133406	130178	130174					
4SE5044L	133151	133406	130178	130174					
4SE5054L	133152	133406	130178	130174					
4SE5032L	133156	133406	130178	130174					
4SE5042L	133157	133406	130178	130174					
4SE5052L	133158	133406	130178	130174					
3SE3024DS	133121	133408	130178	130174					
3SE3034DS	133122	133408	130178	130174					
3SE3044DS	133123	133408	130178	130174					
3SE3054DS	133124	133408	130178	130174					

NOTE:

For a list of components in the kits refer to the pump manual.

* Previous Model Listings



Repair Kit Cross Reference

Pump Model	Pump PN	Pump Manual PN	Seal & Gasket Kit PN	Service / Overhaul Kit PN	Bearing Kit PN	"O" Ring Kit	Cutter Kit PN	BAF PN	BAF-xxxx-CV PN
3SE3024L	133115	133410	130182	130209					
3SE3034L	133116	133410	130182	130209					
3SE3044L	133117	133410	130182	130209					
3SE3054L	133118	133410	130182	130209					
3SE3032L	133153	133410	130182	130209					
3SE3042L	133154	133410	130182	130209					
3SE3052L	133155	133410	130182	130209					
3SE1524HD	133463	133460	130182	130209					
3SE1594HD	133464	133460	130182	130209					
3SE1544HD	133465	133460	130182	130209					
3SE2024HD	133466	133460	130182	130209					
3SE2094HD	133467	133460	130182	130209					
3SE2044HD	133468	133460	130182	130209					

NOTE:
For a list of components in the kits refer to the pump manual.
* Previous Model Listings

Repair Kit Cross Reference

This page intentionally left blank